

Top of the insert is visible with measurement window facing you.

Direction of pull arrow.
Pull towards you!

Pulling hand goes here.



Proper insert head and torque wrench orientation.
Stahlwille Torque Wrenches